

## Lasts 20+ Years

- Apply Z-STOP by butting it up against the ridge cap on both sides of all roof peaks. (see drawing at left) Apply Z-STOP below anything that blocks rain water flow, such as chimneys, gables and skylights. Rain water must run over Z-STOP to become effective.
- On roofs with moss, mildew, or fungus, the existing growth must first be removed, then the root systems must be chemically treated and destroyed. Install Z-STOP to keep it from growing back.
- Nail approximately every two feet with neoprene washered roofing nails.

In areas of severe moss, mildew or fungus growth, several horizontal rows of Z-STOP application may be necessary to assure its effectiveness over the entire roof surface.

Tools Required:

Hammer and Scissors.



MIN. WT. 3 lbs.

ACTIVE INGREDIENTS

"CAUTION: SHARP EDGES"
"KEEP OUT OF REACH OF CHILDREN"

A Product of WESPAC Lynnwood, WA 98037 (800) 845-5863 WWW.z-stop.com

**MADE IN USA** 

SINCE 1984