

Electro-BioCide™

Manufactured By

STRATEGIC RESOURCE OPTIMIZATION, INC. (SRO)

289 Elk Creek Drive • Bailey, CO 80421 • (303) 838-0599

ACTIVE INGREDIENT:

Chlorine Dioxide.....0.02%

OTHER INGREDIENTS:.....99.98%

TOTAL.....100.00%

KEEP OUT OF REACH OF CHILDREN

NET CONTENTS: 1 GALLON

Lot #: _____

Expiration Date: See sticker attached to
container for expiration date

EPA Reg. No. 87492-1
EPA Est. No. 87492-CO-002



RECOMMENDED USE (LOCATIONS): Electro-BioCide™ is a multipurpose bactericidal and virucidal cleaner that disinfects

pre-cleaned hard nonporous surfaces such as stainless steel, chrome, glass, plastic, vinyl, glazed porcelain, glazed ceramic, plastic laminate, sealed terrazzo or granite, linoleum, metal, and finished wood. Recommended for use in: Hospitals, nursing

homes, health care settings, hotels and motels, cruise ships, dormitory rooms, temporary housing, households, public transportation, schools, universities, gymnasiums, locker rooms, restrooms, & fitness centers.

RECOMMENDED USE (SURFACES): Electro-BioCide™ disinfects and is bactericidal and virucidal on the following pre-cleaned hard nonporous surfaces such as stainless steel, chrome, glass, plastic, vinyl, glazed porcelain, glazed ceramic, plastic laminate, sealed terrazzo or granite, linoleum, metal, and finished wood when used as directed: Call bell, over bed

tables, side tables, closets, shelves, drawers, telephone, TV remote, floors, walls, patient equipment, restroom fixtures, & trash cans.

FOR USE AS A DISINFECTANT AND VIRUCIDE: Disinfectant: Electro-BioCide™, when used as directed, is effective against *Pseudomonas aeruginosa*, *Staphylococcus aureus*, *Klebsiella pneumoniae*, *Acinetobacter baumannii*, *Salmonella enterica*, *Staphylococcus aureus* (MRSA), and *Enterococcus faecalis* (VRE) with a 10-minute contact time on pre-cleaned hard

nonporous inanimate surfaces. Virucidal: Electro-BioCide, when used as directed, is effective against Rhinovirus Type 37, Influenza Type A (H1N1) Virus, Hepatitis A Virus, and Human Immunodeficiency Virus Type 1 (HIV-1) with a 10-minute

contact time on pre-cleaned, hard, nonporous inanimate surfaces. This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that [1] is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or [2]

contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to pre-clean or decontaminate critical or semi-critical medical devices prior to sterilization or high level disinfection. To Disinfect: [1] Only trained applicators are permitted to

apply this product [2] Handlers applying chlorine dioxide in an occupational setting must wear gloves [3] Pre-clean all hard, nonporous surfaces with Electro-BioCide™ or detergent prior to disinfection [4] Spray from 4-6 inches all hard, nonporous surfaces until thoroughly wet [5] Allow surfaces to remain wet for 10 minutes [6] Allow surfaces to air dry

TKILLS HIV NO PRE-CLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS in healthcare settings and other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood/body fluids, and in which the surfaces/objects likely to be soiled with blood/body fluids can be associated

with the potential for transmission of Human Immunodeficiency Virus Type 1 (associated with AIDS). SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 OF SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS: Personal Protection: Disposable latex or vinyl gloves, gowns, face masks, and eye coverings as

appropriate, must be worn during all cleaning of body fluids, blood, and decontamination procedures. Cleaning procedures: Blood/body fluids must be thoroughly cleaned from surfaces/objects before application of Electro-BioCide™. Contact Time: Allow surface to remain wet for 10 minutes to kill HIV-1. Use a 10-minute contact time for all other organisms claimed. Disposal of Infectious Material: Blood/body fluids must be autoclaved and disposed of according to

Federal, State, and local regulations for infectious waste disposal. STORAGE AND DISPOSAL: Do not contaminate water, food, or feed by storage or disposal. Pesticide Storage: Store this product in a cool, dry area away from direct sunlight or heat. Always store pesticides in original container. In case of

leaking container, wrap product in secondary container and follow pesticide disposal instructions. In case of spill, contain and flush with water and dispose of waste on site. Pesticide Disposal: Wastes resulting from the use of this product may be disposed of on-site or at an approved waste disposal facility. Call your local solid waste disposal agency or 1-800-CLEANUP for recycling if available or dispose in trash.

Electro-BioCide™